

User manual

Wireless Keyboard Case

(ATS Series & E Series)

* This manual is applicable to multiple versions of wireless keyboard.
Please refer to the final version you received and find the type corresponding to the features.

Step 1: Installing Your iPad into the Keyboard Case

Type A	Install the iPad into the top of the case from the bottom then push iPad into the spring-loaded base. (When you remove your iPad from keyboard case, gently push the corner to avoid broken caused by strong pressure.)	
Type B	The camera hole should be aligned with the camera. (Please note that the iPad should be fully attached to the magnetic cover.)	

Step 2: Turning On/Off the Power Switch

Type A	Push the power button to turn the device on/off. Once the device is turned on, the LED indicator will light up for 3s and then turn off.	
Type B	Long press the "⏻" button to turn the device on/off. Once the device is turned on, the LED indicator will light up for 3s and then turn off.	

Step 3: Establishing Bluetooth Connection

Type A	1. Press and hold the Bluetooth connection button. The blue indicator light will flash, indicating that the keyboard's Bluetooth is waiting for pairing. 2. Open your iPad >> Settings >> Bluetooth, search for "ipad-keyboard" in the list, and then click it to connect.	
Type B	1. Press the combination keys "Fn" and "C" simultaneously. The blue indicator light will flash, indicating that the keyboard is in pairing mode. 2. Open your iPad >> Settings >> Bluetooth, search for "ipad-keyboard" in the list, and then click it to connect.	
Type C	1. When you turn on the power switch of the keyboard, the blue indicator light will be automatic flashing (no need press any Bluetooth icon keys for connection), that indicating the keyboard's Bluetooth is waiting for pairing. 2. Open your iPad >> Settings >> Bluetooth, search for "ipad-keyboard" in the list, and then click it to connect.	

TIPS:

If there is no single more than 30s (some version more than 10s), the backlight will automatically turn off; and no single over 10 min, the keyboard will enter standby mode. At this point, you only need to double-tap any key to reactivate the keyboard again.

LED Indicators:

Power indicator	Red flashing: Low battery warning; Red solid: In charging mode; Green: Battery is fully charged.	 Type A  Type B  Type C  Type D
Bluetooth indicator	Blue flashing: Bluetooth is waiting for pairing; Blue solid: Bluetooth is paired.	 Type A  Type B  Type C
Caps Lock indicator	On: Caps Lock mode is on; Off: Caps Lock mode is off.	 Type A  Type B  Type C

TIPS:

LED indicators may vary for different product versions. Please refer to the final version you received and the corresponding indicator lights above.

Shortcut key Combinations

Please mind that if your keyboard has the following keys to make it work, as it just for optional functions.

Key Combinations	Functions
 + any letter	Input some special characters
 + any letter	
 + 	Switch language input method (Wubi input method is not supported)
 + 	
 + 	Adjust color backlight
 + 	Adjust backlight brightness
 + 	Turn on/off breathing backlight (optional)
 + 	Adjust breathing speed of backlight (optional)

Keyboard Shortcuts

There are two types of keyboard shortcuts as below, some features are optional and only applicable to pointed versions, please refer to the version you have received.

Type A	The shortcut keys needs to be added with  to be implemented. The special symbols needs to be added with  to be implemented.					
						
						

Type B	Directly click the the shortcut keys to be implemented.									
										
										

Description of Each Keyboard Shortcuts

Button icon	Description	Button icon	Description
	Home		Volume up
	Decrease brightness		Voice wake-up
	Increase brightness		Backlight brightness adjustment
	Enable iPad search		Backlight color adjustment
	Virtual keyboard wake-up		Bluetooth connection
	Previous track		iPad screenshot
	Play/Pause		Screenshot
	Next track		Undo input
	Mute		Lock screen
	Volume down		Power Button

Touchpad/Gestures

1. Ensure that the iPadOS operating system is IOS 15.0 or higher;
2. After connect to Bluetooth. Go to iPad -> Settings -> General -> Touchpad Tap to Tap / Two-finger assist point (open) Assistive Touch On;
3. You will see a cursor appear on the iPad screen, when trackpad is successfully turned on;
4. Then go to iPad -> Settings General-Touchpad-Tracking speed (adjust to suitable speed);
5. Press key combinations "fn" + "T" to turn the touch function on/off;
6. Shortcut gestures are based on below default settings;
7. When the Bluetooth connection is turned on, there will be 3s delay on the touchpad function.

One Finger



Tap: Press with one finger until it feels a little bit.

Tap and hold: Press and hold with one finger.



Open "Notification Center": Move the pointer to the status icon in the upper left corner of the screen with one finger, then tap or swipe up again with one finger.



Drag: Tap and hold the item, then slide your finger on the touchpad to move it.



Open the Dock: Swipe the pointer across the bottom of the screen with one finger.

Go to the home screen: When the dock appears, swipe the pointer across the bottom of the screen again.

Double Fingers



Auxiliary tap: Move the cursor to the APP icon with one finger, then tap or tap with two fingers to open the APP menu.



Turn on the Today view: When the home screen or lock screen is visible, swipe right with two fingers.

Open search from the home screen: Swipe down with two fingers.



Scroll up or down: Swipe up or down with two fingers.

Scroll left or right: Swipe left or right with two fingers.



Zoom: Place two fingers close together, spread to zoom in, or pinch to zoom out.

Three Fingers



Open the APP switcher: Swipe up with three fingers, pause and then lift your finger.



Go to the home screen: Swipe up with three fingers.



Switch between open apps: Swipe right with three fingers, then swipe left or right to switch.

Power Supply – Notes :

1. The keyboard case is charged via the TYPE-C interface.
2. Power adapter is not included.
3. Please to fully charge before using it for the first time or when it has not been used for a long time.
4. Please store and charge the device at normal temperatures conditions.

What should i do if the keyboard can not connect to the iPad?

1. When the Bluetooth indicator light stops flashing, it indicates that the device is connected.
2. When reconnecting Bluetooth, there will be a slight delay of about 3s, the touchpad needs to retrieve and connect to Bluetooth.
3. After the initial successful connection, it wil automatically connect back to the last paired device every time it is turn on.
4. You can swipe right on the iPad's home screen to find the bluetooth icon (some version shown on keyboard icon) which shown the battery level for the keyboard, see Figure 1.
5. Multi-device connection is not supported via keyboard case.
6. When the battery level is low, the Bluetooth connectivity may be interrupted.



Figure 1

How to change between lowercase and uppercase on the keyboard?

1. The caps lock default function is switch languages. So to type capital letters on the keyboard, please turn off the cap lock default function first.
2. Go to your iPad settings—Keyboards setting, hard ware keyboard—turn off the toggle of switch languages using caps lock, then you can change between lowercase and uppercase by press the caps lock key.

Warranty and Technical Support

Thank you for purchasing our products, each product is manufactured under strict quality control. If you have any questions about the product, please contact our brand support or visit our official website to obtain the latest user manual.

Please contact Apple Customer Service for settings related to the iPad. Examples of issues include.

Non-functioning keys (e.g, I, J, L, K, M)

Keystroke repetition

Keystroke delays

Tracking sensitivity

Assistive Touch functionality

Caps lock malfunctions

How to configure the QWERTY layout (e.g, Why i press A but get a Z)

Inability to switch input methods